

REMOTE WELL CONTROL KIT

WELLSENTRY™
REMOTE WELL CONTROL

Install a WaterVision™ Well Sentry remote well control kit on your well installation and have access to operate and monitor your pump from anywhere, anytime. WaterVision 2.0 remote telemetry allows you to spend less time and money in the field by gaining greater control and visibility of your operation. WaterVision's real-time alarms and alerts will give you added peace of mind that your equipment is running smoothly and is protected in case of malfunctions. Rich standard options allow you to support a host of monitoring sensors to make your whole system visible like never before.

WELL SENTRY SUPPORTS THE FOLLOWING OPTIONAL FEATURES:

STANDARD ANALOG INPUTS (4-20mA):

- ◆ System Pressure
- ◆ System Flow
- ◆ Water Level
- ◆ Temperature

STANDARD DIGITAL INPUTS:

- ◆ Pump in Auto
- ◆ Pump Running
- ◆ Power Monitor
- ◆ Pump Fault
- ◆ Oiler Fault
- ◆ Low Level Float
- ◆ High Pump Temp Fault
- ◆ Low Inlet Pressure Fault
- ◆ Phase Monitor
- ◆ Vibration Switch

STANDARD RELAY OUTPUTS:


- ◆ Run Pump
- ◆ Run Oiler
- ◆ Pump Start Annunciator
- ◆ Pump Running Light
- ◆ Pump Fault Light

STANDARD CONTROL FEATURES:

- ◆ Pre-lube Timer
- ◆ Backspin Timer
- ◆ User Selectable Text or Email Alerts
- ◆ User Selectable Fault Shut Down, including Pressure, Flow, Level, Amps, Oiler & Vibration

KIT INSTALLED BY AUTHORIZED DEALER OR SERVICE PROVIDER

- ◆ 16x14x7 NEMA 4 Box
- ◆ 7 inch color touchscreen
- ◆ Dead front
- ◆ 1-year warranty
- ◆ 1-year WaterVision subscription included



MONITOR
CONDITIONS
OF
UNATTENDED
EQUIPMENT
IN REAL TIME

Event-Driven Updates
Immediate Alerts
Important Reports




WATERVISION 2.0™

Stay connected and in control of your systems with WaterVision 2.0. This next generation of advanced cloud telemetry adds 24/7 ease and convenience to your operation. Spend less time and money by eliminating site visits and view key information all in one spot.

STANDARD & CUSTOM REPORTS

Water Usage
Water Level Draw Down
KWh/Gallon or Acre/Ft
Event Log



For more information, scan the code, visit watertronics.com, or call 1-800-356-6686.



www.watertronics.com | 1-800-356-6686